
Project 7 Sensor Calibration

Sunday, 2 August 2020 5:09 PM



This system measures the concentration of oxygen in the air at the bottom of a coal mine. As the O2 sensor degrades over time, we will need to calibrate it by comparing its readings to known values.

The sensor we're using reads values from 0% to 40%.

We are given two calibration gases to measure:

- Gas that has exactly 0% 02 concentration
- Gas that has 30% 02 concentration

The system will have two modes:

- Sampling all it does is measure the O2 in the air passing by the sensor
- Calibration more complicated
 - Sequence 1: Open 0% calibration gas valve for 30 seconds, then close it
 - o Sequence 2: Open 30% 02 calibration gas valve for 30 seconds, then close it
 - Sequence 3: Use the average readings over the last 60 seconds and use them to tune itself according to the following:

 $input_{min} = O_{zeroAverage}^2$

$$input_{max} = \left(\frac{O_{maximumConcentration}^2}{O_{CalibrationGasConventration}^2} * (O_{TestGasAverage}^2 - O_{ZeroAverage}^2)\right) + O_{zeroAverage}^2$$

 $O_{maximumConcentration}^2 = 40\%6$

 $O_{CalibrationGasConcentration}^2 = 30\%$

 $O_{TestGasAverage}^{2}$ = Average reading sampled during sequence 2

 $O_{ZeroAverage}^{2}$ = Average reading sampled during sequence 1